

Eco-Rubber Rainbow Turf Pour-in-Place Rubber Surfacing Installation Overview

Notes: The rubber is 100% SBR tire buffings (no metal, no polyester), pigmented with iron oxide pigments. Ratio of rubber to urethane is typically 5 to 1 by weight (Example: Use 60lbs of loose rubber and 12 lbs of urethane).

Tools required: Thin rubber gloves, wheelbarrow, plastic sheeting, duct tape, rake, shovel, trowel, and a small pail of water with some dishwashing soap in the water.

1. Line wheelbarrow with plastic sheeting and duct tape around the sides to hold in place.



2. Clear 2" of sod/dirt from area for rubber to be installed. Place weed blocker on ground.

3. Put on gloves, wet shovel with water/soap mixture to keep from sticking to urethane, use shovel, mix rubber and urethane in wheelbarrow, folding the mixture for 5 minutes.

4. Wet gloves with water/soap mixture to keep from sticking to urethane, mix rubber and urethane in wheelbarrow by hand, until completely even in texture.

5. Pour rubber into prepared area, spread by hand, pat down with trowel or shovel if flat appearance is desired. Rake rubber up with rake if "rough textured" mulch look is desired. Bevel edges with trowel.

6. Installation will be set in 24 hours.

7. Repairs can be completed by cutting out damaged sections then installing new material to replace.



For more information contact:

Eco-\$mart, Inc. (941)376-8484 ph / info@eco-smart.com